



MICRO MIST SYSTEM

sales@jxi.co.za

071 213 7705



JXi



MAXIMISES

INNOVATIVE



Unlike traditional methods, the Micro Mist utilises ultra-fine mist particles created through ultrasound, rather than steam, to deliver treatments effectively.





1 MICRO MIST HEATING

Micro mist is heated to a temperature of 40-50°C (105-125°F), which helps the hair swell. The cuticles on the surface open up during this process.



3 DEEP PENETRATION

Treatment particles penetrate even deeper into the hair shaft, nourishing the cuticles and supplying CMC (cell membrane complex).

2 MOLECULAR ACTIVATION

Heated micro mist activates the molecular movement of treatment particles, allowing them to penetrate the hair through the opened cuticles.

4 COOLING AND FIXATION

By rapidly cooling the air, the treatment particles are fixed firmly onto the hair.

HAIR TREATMENT STEAMER


The Mist Hair Steamer is equipped with advanced features such as controlled **ultrasonic waves**, delivering high-quality results for hair treatment. It represents a **cutting-edge solution** in the world of hair care, specifically designed for salon environments. This premium steamer promotes healthy hair with treatments that are difficult to replicate elsewhere.



JXi
sales@jxi.co.za
071 213 7705

KEY FEATURES

The JXi Mist Hair Steamer is engineered to meet the highest global standards, providing both safety and performance you can trust. Rigorously lab-tested and IEC-approved, the testing facilities adhere to international standards and are accredited members of ILAC and CANS. Additionally, the JXi Mist Hair Steamer is CE-approved, ensuring it meets European safety and quality requirements, and holds NRCS certification, complying fully with South African regulations. This extensive certification process guarantees that the JXi Mist Hair Steamer delivers professional-grade results, while meeting the stringent safety and quality standards of various international markets.



Transparent Hood: Provides visibility and protection during use.

Fabric Hood: Offers an alternative hood option for flexibility.

Control Panel: Simple and intuitive controls for easy operation.

Neck Cushion: Ensures user comfort during the treatment process.

Water Tank: Supports extended use with sufficient water capacity.

Lifting Handle: Allows for convenient adjustments and portability.

Flange: Sturdy base for stability during operation.


JXi

sales@jxi.co.za
071 213 7705

MIST HAIR STEAMER

INSTALLATION

1. Insert four wheels into the holes of the footstool based on directions.
2. Connect the foot stool with direct connection using 10mm bolt to fasten.
3. Insert brace into holes of foot stool, using matching bolt to fasten.
4. Loosen lifting handle, insert main machine into brace (Press main machine to check whether it can rebound), fasten lifting handle.
5. After installing main machine, insert neck cushion into related holes.



JXi

sales@jxi.co.za

071 213 7705

MIST HAIR STEAMER

OPERATION

Auto Mode Operations:

Choose operation mode based on relate auto mode, the presupposed parameter cannot be changed, the machine will work according to the chosen mode:

Auto Modes:

- Oily Hair Mode
- Neutral Hair Mode
- Damaged Hair Mode

Steps to Operate:

- Press the desired mode (e.g. Neutral Hair)
- Press the "Start" button.

Note: The machine will not work unless an operation mode is selected.

Manual Mode:

Time Adjust Key:

- Press to add or reduce time in one-minute increments.
- Long press for continuous adjustment.

Temperature and Capacity Adjust Key:

- Adjust the mist intensity across different levels.
- Press to increase or decrease mist grades.

Cold Fan Program Key:

- Use before or after misting to cool down.
- Preset to run for 3 minutes.

Ozone Program Key:

- Activate before or after misting for additional sanitisation.
- Must be used in conjunction with the cold fan program.

Using Ozone Program

Independently:

- Select the manual mode key.
- Activate the cold fan and ozone program keys.
- Set a working time (e.g., 1 minute).
- Press "Start/Stop" to initiate.
- The ozone mode will run for 3 minutes after the cold fan.

JXi

sales@jxi.co.za

071 213 7705

BASIC PROCESS FOR HAIR TREATMENT



1. Shampooing:

- Dry hair thoroughly with a towel after shampooing.

2. Treatment Application:

- Apply treatment evenly to the hair.
- Ensure hair ends are loose and not overlapping.

3. Setting:

- Adjust the hood and ensure the nape pad is secure.
- Use the face guard for smooth operation and avoid direct contact with the customer's face for hygienic use.

4. Heating:

- The mist effect wraps the head in warmth and creates a salon-friendly visual appeal.
- Customers will find the mist process engaging.

5. Multiple Applications:

- The hood's design allows easy access for multiple treatment applications without readjusting settings.

6. Spa-Like Comfort:

- Offers a luxurious and relaxing experience.

7. Cooling:

- After heating, cooling starts automatically with a fan, refreshing the air and helping the treatment agent set.



JXi

sales@jxi.co.za

071 213 7705

MIST HAIR STEAMER

